

```
In [1]: import keras
keras.__version__
import tensorflow as tf
tf.__version__
```

Using TensorFlow backend.

```
Out[1]: '2.1.0'
```

```

In [2]: # Ignore the warnings
import warnings
warnings.filterwarnings('always')
warnings.filterwarnings('ignore')

# data visualisation and manipulation
import numpy as np
import pandas as pd
import matplotlib.pyplot as plt
from matplotlib import style
import seaborn as sns

#configure
# sets matplotlib to inline and displays graphs below the corresponding cell.
%matplotlib inline
style.use('fivethirtyeight')
sns.set(style='whitegrid', color_codes=True)

#model selection
from sklearn.model_selection import train_test_split
from sklearn.model_selection import KFold
from sklearn.metrics import accuracy_score, precision_score, recall_score, confusion_matrix
from sklearn.model_selection import GridSearchCV
from sklearn.preprocessing import LabelEncoder

#preprocess.
from keras.preprocessing.image import ImageDataGenerator

#dl libraaraies
from keras import backend as K
from keras import regularizers
from keras.models import Sequential
from keras.models import Model
from keras.layers import Dense
from keras.optimizers import Adam, SGD, Adagrad, Adadelta, RMSprop
from keras.utils import to_categorical
from keras.callbacks import ReduceLROnPlateau
from keras.models import load_model

# specifically for cnn
from keras.layers import Dropout, Flatten, Activation
from keras.layers import Conv2D, MaxPooling2D, BatchNormalization
from keras.layers import InputLayer

import tensorflow as tf
import random as rn

# specifically for manipulating zipped images and getting numpy arrays of pixel values
import cv2
import numpy as np
from tqdm import tqdm
import os
from random import shuffle
from zipfile import ZipFile
from PIL import Image

from keras.applications.resnet50 import ResNet50

```

```
import smtplib
from email.mime.multipart import MIMEMultipart
from email.mime.text import MIMEText
from email.mime.base import MIMEBase
from email import encoders
```

```
In [3]: os.listdir('mask_dataset')
```

```
Out[3]: ['0', '1']
```

```
In [4]: def assign_label(img,label):
        return label
```

```
In [5]: def make_train_data(label,DIR):
        for img in tqdm(os.listdir(DIR)):
            path = os.path.join(DIR,img)
            img = cv2.imread(path,cv2.IMREAD_COLOR)
            img = cv2.resize(img, (IMG_SIZE,IMG_SIZE))

            X.append(np.array(img))
            Z.append(str(label))
```


```
In [6]: X=[]
        Z=[]
        IMG_SIZE=150
        NOMASK='mask_dataset/0'
        MASK='mask_dataset/1'

        make_train_data('NOMASK',NOMASK)
        make_train_data('MASK',MASK)
```

```
100%|██████████| 509/509 [00:00<00:00, 732.22it/s]
100%|██████████| 483/483 [00:01<00:00, 369.23it/s]
```

```
In [7]: fig,ax=plt.subplots(2,5)
plt.subplots_adjust(bottom=0.3, top=0.7, hspace=0)
fig.set_size_inches(10,10)

for i in range(2):
    for j in range(5):
        l=mn.randint(0,len(Z))
        ax[i,j].imshow(X[l][:,:,:,:-1])
        ax[i,j].set_title(Z[l])
        ax[i,j].set_aspect('equal')
```



```
In [8]: le=LabelEncoder()
Y=le.fit_transform(Z)
Y=to_categorical(Y,2)
print(Y)
X=np.array(X)
#X=X/255

x_train,x_test,y_train,y_test=train_test_split(X,Y,test_size=0.25,random_state=13)

np.random.seed(42)
mn.seed(42)
#tf.set_random_seed(42)
```

```
[[0. 1.]
 [0. 1.]
 [0. 1.]
 ...
 [1. 0.]
 [1. 0.]
 [1. 0.]]
```

```
In [9]: base_model=ResNet50(include_top=False, weights='imagenet',input_shape=(150,150,3))
base_model.summary()
```

Model: "resnet50"

Layer (type)	Output Shape	Param #	Connected to
=====			
input_1 (InputLayer)	(None, 150, 150, 3)	0	
=====			
conv1_pad (ZeroPadding2D)	(None, 156, 156, 3)	0	input_1[0]
=====			
conv1 (Conv2D)	(None, 75, 75, 64)	9472	conv1_pad[0]
=====			
bn_conv1 (BatchNormalization)	(None, 75, 75, 64)	256	conv1[0][0]
=====			

```
In [10]: model=Sequential()
model.add(base_model)
model.add(Dropout(0.20))
model.add(Dense(2048,activation='relu'))
model.add(Dense(1024,activation='relu'))
model.add(Dense(512,activation='relu'))
model.add(Dense(2,activation='softmax'))
```

```
In [11]: epochs=100
batch_size=128
red_lr=ReduceLROnPlateau(monitor='val_acc', factor=0.1, min_delta=0.0001, patience=5)
base_model.trainable=True # setting the VGG model to be trainable.
model.compile(optimizer=Adam(lr=1e-5), loss='categorical_crossentropy', metrics=['accuracy'])
model.summary()
```

Model: "sequential\_1"

Layer (type)	Output Shape	Param #
resnet50 (Model)	(None, 2048)	23587712
dropout_1 (Dropout)	(None, 2048)	0
dense_1 (Dense)	(None, 2048)	4196352
dense_2 (Dense)	(None, 1024)	2098176
dense_3 (Dense)	(None, 512)	524800
dense_4 (Dense)	(None, 2)	1026
Total params: 30,408,066		
Trainable params: 30,354,946		
Non-trainable params: 53,120		

```
In [12]: from keras.models import load_model
model = load_model('model.h5')
```

```

In [20]: path="mask_check/"
files=os.listdir(path)
for i in files:
    X=cv2.imread(path+i)
    X=cv2.resize(X,(150,150))
    plt.figure()
    plt.imshow(X[:,:,:-1])
    plt.show() # display it

X = np.array(X)
# X = X/255
X = np.expand_dims(X, axis=0)

#print(np.round(model.predict(X)))
fire=int(np.round(model.predict(X))[0][0])
if fire==0:
    print("Absence of mask detected")

fromaddr = "sreedhar.uniq@gmail.com"
toaddr = "sreedharsachu1401@gmail.com"

# instance of MIMEMultipart
msg = MIMEMultipart()

# storing the senders email address
msg['From'] = fromaddr

# storing the receivers email address
msg['To'] = toaddr

# storing the subject
msg['Subject'] = "no mask"

# string to store the body of the mail
body = "Not wearing any mask"

# attach the body with the msg instance
msg.attach(MIMEText(body, 'plain'))

# open the file to be sent
filename = str(i)+".jpg"
att=path+i
attachment = open(att, "rb")

# instance of MIMEBase and named as p
p = MIMEBase('application', 'octet-stream')

# To change the payload into encoded form
p.set_payload((attachment).read())

# encode into base64
encoders.encode_base64(p)

p.add_header('Content-Disposition', "attachment; filename= %s" % filename)

```

```
# attach the instance 'p' to instance 'msg'
msg.attach(p)

# creates SMTP session
s = smtplib.SMTP('smtp.gmail.com', 587)


# start TLS for security
s.starttls()

# Authentication
s.login("sreedhar.uniq@gmail.com", "1017875reg")


# Converts the Multipart msg into a string
text = msg.as_string()

# sending the mail
s.sendmail(fromaddr, toaddr, text)

# terminating the session
s.quit()
else:
    print("mask present")
```



Absence of mask detected





mask present



In [ ]:

In [ ]: